



KIA CEE'D


Answering an incoming call:	Press	MODE
Hanging up a call:	Press 2 seconds	MODE
Rejecting a call:	Press 2 seconds	MODE
Voice dialling:	Press	MODE
Last number redialling:	Press 2 seconds	MODE
Discreet mode:	Press	MODE
Back to car kit mode:	Press	MODE
Turning the volume up:	Press	VOLUME ↑
Turning the volume down:	Press	VOLUME ↓
Entering menu functions:	Press TWICE	MODE
Scrolling menu functions:	Press	VOLUME ↑
		VOLUME ↓
Confirming a function:	Press	MODE
Cancelling a function:	Press 2 seconds	MODE
Entering MUSIC mode:	Press 3 times	MODE
Scrolling songs:	Press	SEEK <
		SEEK >
Leaving MUSIC mode:	Press 3 times	MODE
Car kit resetting:	Press	VOLUME ↓ followed by
		VOLUME ↑ 5 TIMES



BUS 1 Connection



CONNECTIONS



SWITCHES SETTINGS

