



O.A.S.i



Video in motion

FIBER OPTIC UNLOCKER VIDEO INTERFACE



AUDI
BMW
VOLKSWAGEN

WARNING:

For safety reasons
whenever the vehicle engine
is turned off, the block will be
automatically
restored.

The choice to unlock
video/images in motion, only
depends on driver
will, who must completely
assume the responsibility of it.

AUDI MM1 2G / 3G

UNLOCK ACTIVATION:

Press and hold the left castor (the same used to scroll songs list) for 4/5

UNLOCK DEACTIVATION:

Press and hold the MODE key for 4/5seconds

BMW F SERIES (X3 2011>/ SERIES5 AND GT 2010> /SERIE 7 2010>)

UNLOCK ACTIVATION:

Press and hold the right castor (SEEK) for 4/5 seconds

UNLOCK DEACTIVATION:

Press and hold the right castor (SEEK) for 4/5 seconds

AUDI MMI 4G (AUDI A6 A8 2011>)

UNLOCK ACTIVATION:

Press 3/4 times in succession the left castor key (the same used to scroll songs list)

UNLOCK DEACTIVATION:

Press and hold the left castor (the same used to scroll songs list)

VOLKSWAGEN TOUAREG 2010


UNLOCK ACTIVATION:

Press 4 times in succession the OK key

UNLOCK DEACTIVATION:

Press and hold the OK key for 4/5 seconds

LED



RED LIGHT ON = video unlocked

RED LIGHT FLASHING = Car not recognized


YELLOW LIGHT ON = Optical network activated

YELLOW LIGHT OFF = Optical network cut off or deactivated

GREEN LIGHT ON = OASi on

GREEN LIGHT OFF = OASi off

WIRE CONNECTIONS



OPTICAL FIBER

Connect to car optical ring being careful to the beam direction.

All the connectors, also the original ones, indicate the beam movement direction.

Connect the optical fibre as shown in the diagram, respecting the beam movement direction.



OEM CAR CONNECTION



OASi FIBER OPTIC CONNECTION

